




ASSEMBLY INSTRUCTION

NC3FXCC | Female XLR Cable Connector RF-protected



- A** Slide the boot onto the cable.
- B** Prepare cable as shown. Fold back the shield. If the cable does not offer a drain wire, twist a part of the shield for contact # 1 shield wiring.
- C** Slide the crimp strain relief onto the cable jacket to the position as indicated.
- D** Crimp the strain relief by means of HEX crimp dies of width 6.5 mm (size "E" acc. to IEC 60803).
- E** Solder the wire ends to contacts # 2 and # 3 and the shield to # 1 of insert.
- F** Position the distance sleeve between strain relief and insert.
- G** Align the nose of the crimp strain relief and the recess of the distance sleeve with respect to one of the keyways. Slide the unit into the connector housing.
- H** Finish the installation by turning the bushing onto the connector.

NOTE: To keep the strain relief in the keyway, avoid rotation of the cable during assembly.



XLR Connectors:
Find more details on
www.neutrik.com

Neutrik AG LI T: +423 / 237 24 24 F: +423 / 232 53 93
Neutrik USA Inc. USA T: +1 704 / 972 3050 F: +1 704 / 438 9202
Neutrik (UK) Ltd. UK T: +44 1983 / 811 441 F: +44 1983 / 811 439
Neutrik Vertriebs GmbH DE/NL/AT/DK T: +49 8131 / 280 890 F: +49 8131 / 280 830

Neutrik France FR T: +33 1 / 4131 6750 F: +33 1 / 4131 0511
Neutrik Tokyo Ltd. JP T: +81 3 / 3663 4733 F: +81 3 / 3663 4796
Neutrik Hong Kong Ltd. HK T: +852 / 2687 6055 F: +852 / 2687 6052
Neutrik India Pvt. Ltd. IND T: +91 / 982 05 43 424 F: +91 / 22 26163 540

Draft. Nr.: BDA 094 | Update: 2020-07-07 | Data subject to change without prior notice. © 2020 NEUTRIK®. NEUTRIK® are registered trademark of Neutrik AG. ALL RIGHTS RESERVED.

www.neutrik.com

NEUTRIK